



Installation Instructions

Suction Cup Kit for Fixed SLIM VESA Mount Ideal for Glass Surfaces

This kit includes:

- (1) Alcohol Wipe
- (3) Suction Cups
- (3) Tightening Screws

1. Using the alcohol wipe, clean the glass surface where we will be mounting the wall plate. Be sure the surface is free of dirty, grime, or other debris to ensure a secure installation.

Note: Take the time & effort to properly clean the glass surface. Any contaminants will compromise the suction cup kit's strength. Additional cleaning may be required above and beyond using the supplied alcohol wipe to ensure the surface is truly clean.

2. Next, insert the (1) of the (3) suction cups screws into the wall mount we are using. (An example is shown on the right with our "Fixed Slim VESA wall bracket.")

3. **MAKE SURE THAT THE SUCTION CUP IS PUSHED ALL THE WAY IN FIRMLY.**

4. Repeat steps 2 to 4 for all (3) holes of the wall mount, so that there are a total of (3) suction cups installed.

5. [OPTIONAL] For extra strength, drill the (3) tightening screws into the center of the suction cups.

6. The VESA mount is now ready for use, and be stuck directly onto any glass wall! Install the VESA mount as you see fit. The installation is now finished.



Insert
suction
cups as
shown
(3 total)

